

<p>Description</p> <p>Open a circuit automatically in the case of an earth leakage fault between phase and earth or neutral or equal to 30mA. Use in domestic Commercial installations.</p> <p>Technical data</p> <p>Temperature: -5°C to 40°C</p> <p>2 poles 127V - 230V</p> <p>Requency 50Hz</p> <p>Specifications: IEC61008-1 SS97</p>	<p>Positive contact indication:</p> <p>Mechanical indicator, appearing on the front face on RCCB</p> <p>Linked to the contact shows the Positive contact indication:</p> <p>Connection capacity</p> <p>16 - 63A</p> <p>16mm² flexible</p>	<p>Nuisance tripping</p> <p>All the RCCBs are protected against transient voltages (lightning, line disturbances) and transient currents (from high capacitive circuits).</p>
---	---	--



Sensitivity IΔn	Code 2P	Description	Pack Q'ty
High sensitivity 30mA	CD616B	MCB 2P 16A 30mA	1
	CD625B	MCB 2P 25A 30mA	1
	CD640B	MCB 2P 40A 30mA	1